

CAL SE

002500

E

# VARITRANS COMFORTDRIVE

CENTO

Fully automatic operating system for glass panel partitions

## **THE FULLY AUTOMATIC GLASS PARTITION OPERATOR.** VARITRANS COMFORTDRIVE. OPENING UP NEW HORIZONS.

Quick and easy frontage, foyer and showroom adaptation.


The Varitrans ComfortDrive is the fully automatic partition within the Varitrans portfolio – a model that offers outstanding convenience in flexible space utilisation. At the push of a button it enables showrooms and presentation areas, foyers, shops and self-service zones in banks to be adapted quickly and efficiently to daily changing requirements. With this system, multi-functional space management is a truly simple affair. Advanced technology – the ComfortDrive operating system.

With the Varitrans ComfortDrive, transparent partition elements can be moved to their individually preprogrammed positions under fully automatic control. The control interface takes the form of a user-friendly touch screen. A high level of safety is ensured by an integrated monitoring system that stops the partition motions the moment contact is made with an obstacle. Spatial management at the push of a button.

The Varitrans ComfortDrive can be controlled with just one finger operating a central touch screen. Aside from the standard functions "Open", "Close" and "Stop", a number of special positioning modes such as "One element open" ("Personnel opening" function), "Gapped configuration" or various free positioning patterns can be individually programmed and selected.

### CONTENTS

Benefits	3
Technical data	4
Partition layout, operating behaviour	5
Track configurations, basic functions	6
Extended/special operating modes	6/7
Vertical sections	8
Track design details	9
Element interconnection, track suspension systems	10
Floor guides, stacking tracks	11
Element types / Locking device	12/13
Touch panels	14
Cabling diagram	15






### THE BENEFITS AT A GLANCE

- Fully automatic actuation at the push of a button
- Exceptional convenience with dynamic opening and closing speeds of up to 250 mm/s
- Easy operation with selfexplanatory touch screen
- Aesthetically elegant with slender track of just 98 mm in width
- Several element types and partition systems can be combined within one layout
- High level of safety ensured by an integrated monitoring system that stops and reverses the partition on contact with an obstacle – TÜV safety-tested
- Corresponds to the technical Rules for Workplaces – Doors and gates (ASR A1.7), the UVV and VDE regulations

- Smart control system: elements communicate while on the move
- Individually programmable for custom configuration
- Parameterisable microprocessor control (bus system) for activation and monitoring of the operational sequence and functions
- Last element equipped with an electro-mechanical lock to prevent unauthorised operation
- In the event of a power failure, the partition can be manually operated
- Up to 30 elements per partition system, with up to 50 metres of track
- Element heights up to 4,000 mm
- Single element weights up to 250 kg
- High spatial configuration flexibility





### TECHNICAL DATA


General specifications	с
Track width	9
Operator height	2
Max. length with one control unit	5
Max. number of elements	3
Element width	6
Max. element height	4
Max. element weight	2
Radius (directional changes)	1
Track layouts	S
	S
	ci (r
Hold-open time, personnel access	
Travel speed	d
	u
Force limited to	1
Parameterisation	N
Power consumption, stand-by mode	2
Max. power consumption (20 elements)	1,
Electro-mechanical locking device	•
Manual unlocking	•
TÜV safety-tested	•
Line fuse	10
Power supply	2
Power supply within operator	3
Class of protection	

ComfortDrive
98 mm
238 mm
50 m
30
600 – 1,500 mm
4,000 mm
250 kg
150 mm
straight and
segmented
curved
(min. radius 3 m)
variable
dynamic response
up to 250 mm/s
150 N
with laptop
20 W
1,000 W
•
•
•
16 A
230 V AC
36 V DC
III

Touch panel functions Basic functions	
Basic functions	
OPEN	•
CLOSE	•
STOP	•
Extended basic functions	
Partial opening / Partial closing	0
Personnel opening	0
Gapped configuration	0
Special modes	
Zonal opening	0
Free positioning	0
Key switch for personnel access	0
Emergency power module	0
Floating contact	•
Bus interface	•
Status feedback signalling	•

• Standard O Option


### SYSTEM STRUCTURE



- 1. Ceiling-mounted load-bearing guide track with busbar system and cover
- 2. Driven carriers with element suspension mountings
- 3. Non-driven carriers with element suspension mountings
- 4. Glass partition elements
- 5. Floor-recessed guide track
- 6. Floor guide pin fitted to each partition element




### PARTITION LAYOUT



### **OPERATING MODES**

In all operating modes, the partition elements are moved to their preprogrammed positions under fully automatic control. The operating behaviour is dynamically adapted according to where an element is currently loca-ted and where the preceding and following elements are positioned at any given moment in time. **The system operating behaviour can be adjusted by parameter reconfiguration**.

### **OPERATING BEHAVIOUR**



Acceleration: As soon as an element receives the command to go, it checks to ensure that the way ahead is free and then accelerates to the preprogrammed speed.

Fast speed: If the way ahead is unimpeded over a good distance, the element is accelerated to the highest speed of travel. **Creep speed:** The element switches to creep mode to travel the final few inches to its preprogrammed position.

**Deceleration:** As the element approaches its preprogrammed position, the speed is reduced to the required creep value.


**Stop:** The element stops once it has reached its preprogrammed position.

**Staggered travel mode:** The element follows the preceding element at a defined distance as they move into their respective positions.

Waiting: Although elements may have received the command to go, they remain in waiting mode until the way ahead is free.

### TRACK CONFIGURATIONS

#### Example applications




### **BASIC FUNCTIONS**

#### OPEN




All elements move under fully automatic control to the OPEN position.

#### CLOSE



All elements move under fully automatic control to the CLOSED position.

#### STOP




Immediate interruption of all travel functions.



### EXTENDED BASIC FUNCTIONS


(optional)

#### PARTIAL CLOSE




Partial opening or closing of partition. The number of elements affected can be preset by parameter configuration.

#### PERSONNEL OPENING



Partial open mode (personnel access). The number of elements that open or close can be preset by parameter configuration.

#### GAPPED




Positioning of the elements at a preprogrammed distance apart. The number of elements and the gapping distance can be preset by parameter configuration.

### SPECIAL OPERATING MODES


(optional)

ZONAL OPENING Example 1




Certain areas of the partition can be opened. The position and number of elements can be preset by parameter configuration.

#### ZONAL OPENING Example 2



Certain areas of the partition can be opened. The position and number of elements can be preset by parameter configuration.

#### FREE POSITIONING




This mode offers the possibility of placing the elements at any track location.




### VERTICAL SECTIONS

#### Vertical section


with a Varitrans CompactLine element



Vertical section with a Varitrans MetalLine element



#### Vertical section through track






1. Busbars (contact rails)


2. Running surfaces 3. Track profile 4. Track covers

### TRACK DESIGN DETAILS


#### Track rail



#### Non-driven carrier




#### Driven carrier




- 1. Driven roller
- 2. Non-driven roller
- 3. Collector
- 4. Roller head
- 5. PCB
- 6. Drive gear
- 7. Motor
- 8. Support frame
- 9. Carrier pin

#### Track interconnection




### STACKING TRACK OPTIONS

The stacking tracks serve to store the elements in a compact stack and can – depending on the room size and shape – be located within a very small area for maximum spatial efficiency. The low weight of the elements and the advantages that this brings in terms of the structural building requirements that need to be fulfilled are particularly beneficial in the stacking areas. The following shows our standard stacking track arrangements. Custom solutions to meet specific requirements can also be provided on request.






### FLOOR GUIDES




### SUSPENSION SYSTEMS

The track suspension system is selected on the basis of the specific application requirements. The following examples show the most common suspension systems used for the partition track type in question.



### COMPACTLINE - TOUGHENED GLASS, GLAZING RAILS





Closure flap

Fixed full-height passdoor, electrically operated

### COMPACTLINE - TOUGHENED GLASS, ALU-FRAMED

EE






Fullwall element


Corner element

WE




Angle element 99° - 175°

wк



Closure flap

#### FTE




Fixed full-height passdoor, electrically operated




### **METALLINE**









Fullwall element

Corner element








Passdoor, H-frame

### LOCKING DEVICE




The locking device takes the form of an electro-mechanic-ally operated deadbolt designed to engage and secure the elements. It is fitted to the track rail and is mainly used to lock the closed partition. It is usually located at the closure element of a glass panel partition. The locking device is equipped with two sensors that detect and signal the ENGAGED and DISENGAGED end positions of the deadbolt. There are two further sensors to signal whether the locking device is locked. One of these two sensors has a floating contact and can be connected to an alarm system.

### AUXILIARY EQUIPMENT

#### Touch panel with display for control and programming functions


All the functions of the Varitrans ComfortDrive can be controlled with just one finger operating the buttons of the central touch screen. Aside from the standard functions "Open", "Close" and "Stop", a number of special positioning modes such as "Personnel opening", "Gapped configuration" or various free positioning patterns can be individually programmed and selected. A bus link with the building control system can also be provided.

#### Standard display: Key pad




#### Premium display: Touch display







#### Cabling/wiring diagram



#### COMFORTDRIVE FOR SOUND-INSULATING PARTITIONS





Fully automatic partition system with Variflex elements.

For more information, please see the brochure: "Variflex ComfortDrive – Fully automatic operating system for sound insulating partitions".

If you don't have the brochure, we will be glad to send you one.



dormakaba Group



#### DORMA Hüppe Raumtrennsysteme GmbH + Co. KG Industriestraße 5 26655 OCHOLT GERMANY Phone +49 4409 666-0 Fax +49 4409 666-489 info-hueppe@dormakaba.com www.dorma-hueppe.com



#### DORMA Hüppe Austria GmbH

Hollabererstraße 4b 4020 LINZ AUSTRIA

Phone +43 732 600451 Fax +43 732 650326 office@dorma-hueppe.at www.dorma-hueppe.at